

**TROLEX**

**XXD1+**

**QUICK START  
GUIDE**

Register your warranty online  
at [www.trolex.com/register](http://www.trolex.com/register)

## 1. CHARGE

Connect your **XCD1+** to a USB wall charger or Mac or PC device to top up the battery.



Ensure your device is fully charged. The battery icon will flash green when charging is complete.



## 2. DOWNLOAD

Download the **BreathelITE** software onto your PC or laptop.



[trolex.com/breathelite-download](https://trolex.com/breathelite-download)



## OR...

Download **BreathelMOBILE** for free from the Apple or Google Play stores.



### 3. CUSTOMISE

Set your custom parameters in **BreatheLITE**, which will auto-identify each **XCD1<sup>+</sup>** connected.



### 4. MOUNT

Attach your **XCD1<sup>+</sup>** using the alligator clip provided.



Mounting options available.

## 5. SAMPLE

You are now monitoring dust concentrations in your environment.



STEL



TWA



Audio  
alarms



Vibration  
alerts

## 6. ALERT

Record exposure data and receive automated real-time alerts when dust thresholds are breached.

## 7. REVIEW

Connect to **BreatheLITE** via USB to review, analyse and download device data.

Or view in real time using your **BreatheMOBILE** app.

